



R-9501

USER MANUAL

SAFETY MEASURES

Before using the device, please, attentively read these instructions and keep them for the whole operation period.

Before switching on make sure that the voltage of the electric network corresponds to the operating voltage of the unit.

Place the unit on the flat, moisture-resistant surface. Distance from the walls should be not less than 15 cm.

Do not direct the nozzle of the unit at the wooden furniture, electrical appliances, books and objects, which can be damaged by moisture.

Do not place the humidifier in the places subjected to direct sun light, high temperatures, near computers or other sensitive electronic appliances.

Do not leave the unit unattended in closed rooms otherwise condensation can appear on the furniture and the walls, that is why we recommend keeping the door of the room, where the humidifier is used, half-opened.

It is forbidden to use the device out of doors.

Use only the removable parts which are supplied with the unit.

Do not allow children to use the kettle as a toy.

This unit is not intended for usage by children or disabled persons. This unit is not intended for usage by children or disabled persons unless they are given all the necessary instructions on safety measures and information about danger, which can be caused by improper usage of the unit.

Do not switch on the unit without water. Disconnect the unit from the power supply when the water tank becomes empty.

Do not use soda water or any perfume additives.

Always unplug the unit and before taking the water tank out of the unit.

Do not block steam outlets and provide that foreign objects do not get inside them.

Do not immerse the unit, the power plug or the power cord into water or other liquids.

Do not move or tilt the unit during its operation.

Always unplug the unit and pour out water from the water tank during cleaning the unit, if you do not use it.

Unplug the unit before moving it to another place.

Do not touch the power plug with wet hands.

Before using the unit, closely examine the power cord and make sure that it is not damaged. Do not use the unit, if its power cord is damaged.

Do not dismantle the unit yourself, if any malfunction is detected, apply to the nearest authorized service center.

Regularly clean the unit; do not allow cracks to appear on the sprayer

FOR HOUSEHOLD USAGE ONLY

BEFORE USING THE UNIT FOR THE FIRST TIME

Unpack the unit and remove the packing materials. Examine the unit for damages. Do not switch on the unit if there are any damages in it.

Note:

if the unit was subjected to negative temperatures, before switching it on for the first time, keep it at room temperature for 30 minutes.

use the unit at +5 - +40°C temperature, and relative humidity less than 80%.

water temperature should not exceed +40°C.

Before switching on the unit, make sure that the voltage of the electric network corresponds to the operating voltage of the unit.

Using the ultrasonic air humidifier

1. Remove the nozzle (1) from the water tank (2).
2. Remove the water tank (2) from unit.
3. Turn over the tank (2); unscrew the lid (3), by turning it anti clockwise.
4. Fill the water tank (2) with necessary quantity of water and screw the lid (3), by turning it clockwise.
5. Set the filled tank (2) on the body of the unit.
6. Insert the plug into the socket.
7. Switch on the unit, by turning the switch (5) clockwise, the indicator (6) will light green.
8. Regulate steam intensity by turning the regulator (5).
9. If there is no water in the water tank (2) the indicator will light red
10. Use the switch (5) to switch off the unit and then unplug it. Fill the tank (2) with water and set the filled tank on the body of the unit.
11. Upon termination of work turn the unit off by turning the regulator (5) counter-clockwise up to full stop, the indicator of operation (6) will go out.

Clean and care

Always switch off and unplug the unit before cleaning.

Hard water causes appearance of scale on the “sprayer”(4) and in the operating chamber; it leads to improper operation of the unit and appearance of white deposit on the interior objects. To avoid it:

- . use boiled water or water, which stood for some time, water, purified by filter or distilled water;
- . clean the operating chamber (4) weekly;
- . change water in the water tank (2) more often.

Weekly care

- Once a week carefully wash the water tank (2) and the operating chamber (4) with a neutral washing liquid solution. After it rinse them thoroughly with water.
- Add 5-10 drops of the cleaning agent on the “sprayer” (4); wait about 2-5 minutes. Use the brush (7) to remove the deposit from the surface of the “sprayer” (4).

Note:

- As a cleaning agent for the “sprayer” you can use substances for scale removal in kettles.
- Do not immerse the unit into water or other liquids.

ENGLISH

Storage

Before taking the unit away for storage, pour out water from the water tank (2) and from the operating chamber (4), wipe the operating chamber (4) dry.

Do not store the unit with water in the water tank or if water remains in the operating chamber.

Keep the humidifier in a dry cool place out of reach of children.

TROUBLESHOOTING

Failure	Possible causes	Troubleshooting
The operating indicator is not lighting, no steam formation	No voltage, no power supply	Plug the unit
		Plug in another, properly operating device, to make sure that the socket is in good operating condition.
The operating indicator is lighting red, no steam formation	There is no water in the water tank.	Fill the water tank with water.
“Steam” has an unpleasant smell	New device – it is normal	Unscrew the lid of the water tank, pour out water and leave the unit for 12 hours in a cool dark place
	Polluted or stagnant water	Unplug the unit, remove the water tank, pour out water, wash the water tank, and fill the water tank with boiled or distilled water.
Small intensity of “steam” output	Polluted “sprayer”	Unplug the unit and clean the sprayer.
Abnormal noise during operation of the unit	The unit is placed on the uneven or unstable surface	Unplug the unit and even the body of the unit or move the humidifier to another place.

NOTE:

Non-observance of rules for cleaning the unit from mineral deposits caused by hard water may affect the overall performance of the unit. In this case clean the unit. If used water is too hard, use household filters to purify water or mix tapping water with distilled water in proportion 1:1.

Warning:

- 1, This appliance is not intended for use by persons (including children) with reduced physical sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- 2, Children should be supervised to ensure that they do not play with the appliance.
- 3, If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- 4, Unplug the appliance during filling and cleaning.
- 5, This appliance is intended used for household and indoor use only.

IMPORTANT INFORMATION FOR CORRECT DISPOSAL OF THE PRODUCT IN ACCORDANCE WITH EC DIRECTIVE 2002/96/EC.

At the end of its working life, the product must not be disposed of as urban waste. It must be taken to a special local authority differentiated waste collection centre or to a dealer providing this service.

Disposing of a household appliance separately avoids possible negative consequences for the environment and health, deriving from inappropriate disposal and enables the constituent materials to be recovered to obtain significant savings in energy and resources. As a reminder of the need to dispose of household appliances separately, the product is marked with a crossed-out wheeled dustbin.